


Magnetic Lock Door Riser Diagram



Materials / Equipment List

1. LockState Access Control System Main Board or Expansion Panel
2. LockState PIN and or Proximity Reader
3. Magnetic Lock
4. Request to Exit Motion Sensor
5. Exit Button

Cable Type List

6. 22 gauge 6 conductor copper stranded cable with over all shield for card reader
7. 18 or 16 gauge 6 conductor copper stranded for Electric Strike. If running > 100' use 16 gauge.
8. Cat5E or Cat6 for Ethernet connection to Controller
9. Included Power Cord
10. 18 gauge 2 conductor copper stranded



LockState
 1325 S. Colorado Blvd Suite 400 **Technical Support:** 888-478-7225
 Denver, CO 80222